

Figure 4-1
Front Panel Controls and Functions





Figure 10-3
Left Side View



*THE NUMBER AND TYPE OF
IR CELLS WILL VARY DEPENDING ON
THE INSTRUMENT MODEL. REFER TO
THE ILLUSTRATION SECTION OF THIS
MANUAL FOR PART NUMBERS)

Figure 10-4
Right Side View